

R-1-X-LM Supplement

One-Channel Square Wave Input and One-Channel Mag Input

Note: X = Number of Cylinders (2,4,6,8, etc.)

1. Install the R-1 instrument per the Installation Instructions.
2. Connect the green lead (Pin 7) to the Mag (P-Lead) via an isolator/resistor.
3. Connect the white lead (Pin 8) to the square wave tach out signal of the electronic ignition system. Do not use an isolator/resistor.

R-1-X-LM

Supplemental Instrument Wiring Diagram - Only For Pin 7 and Pin 8

